

## Replacing the front glass

Product code 51297 contains: 1 front glass

The following tools are needed: A wrench

Flat nose pliers or tool to mount the Bauart spring, buy [here](#)

### How to change the front glass step by step:

- Open the door
- Remove the [bauart](#) spring by using pliers or a [special tool](#).
- Remove the two pins which hold the door and take the door out. If the pins are secured, remove the safety rings by using pliers.
- Place the door face down on a soft material to protect the paint.
- Remove the brackets holding the glass in place.
- Remove the glass and mount the new glass. Please note that we recommend you exchange the gaskets when exchanging the glass. They can be bought [here](#).
- Remount the brackets that hold the glass in place. Avoid direct contact between steel parts and glass.
- Position the door in place and mount the 2 pins (and the safety rings) in the hinges.
- Remount the bauart spring. However, this is only mandatory in Germany.

Hereafter you can use your stove again.